Model #

2420DUETb Addi Writing Desk

Duet = Natural finishAssembly Instructions



Thank you for allowing us to help you furnish your home. We are certain you will be delighted with your new furniture for many years to come.

IMPORTANT NOTES:

- Wood can be susceptible to changing color over time when exposed to strong sunlight. Use window shades, drapes or blinds to protect your furniture. To help the surface age evenly and avoid dark and light spots, periodically move items to expose the entire surface to an even amount of light so it may develop a uniform patina.
- For normal household use only. Not recommended for commercial use.
- Do not climb, sit or stand on this piece of furniture.
- Do not overload the drawer.
- Unload items before you move this unit.
- Use a protective pad when you use the top of this piece as a writing surface
- This assembly requires two people.

MARNING

Drilling, sawing, sanding or machining wood products can expose you to wood dust, a substance known to the state of California to cause cancer. Avoid inhaling wood dust or use a dust mask or other safeguards for personal protection.

For more information go to: www.p65warnings.ca.gov/wood

This product can expose you to chemicals, including formaldehyde, which are known to the State of California to cause cancer. For more information go to: www.p65warnings.ca.gov/furniture

DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.

CUSTOMER SERVICE

If you ever have questions about your furniture, please do not hesitate to contact us. In the unlikely event you need a replacement part; we can make those parts available through an authorized Whittier Wood Furniture dealer. If you cannot order replacement parts through your dealer, please contact our customer service department.

Hours: Our friendly customer service staff can be reached:

Monday-Friday 8:00 a.m. to 5:00 p.m. (Pacific Time).

You may leave a message 24 hours a day, seven days a week.

Customer Service: 800-653-3336 • Outside the U.S.: 541-687-0213

Fax: 541-687-2060 Email: info@whittierwood.com



2420DUETb Addi Writing Desk

Parts List

Please identify the parts and check that quantities received match those on this list. If you need to replace a part, refer to the following letter and part name.


Part	Description		Quantity
Aa	Top Assembly		1
В	Drawer (inserted)		1
С	Leg Assembly	1 8 9	4
D	#6 x 5/8" Philtruss Screw (inserted)		12
E	#8 x 1-3/8" Lo-Profile Screw (inserted)	accecececa	20
F	#8 x 1-3/4" Pan Head Screw (inserted)		28
G	#8 Washer (inserted)	(<u>)</u>	28
Н	1/4" x 20mm Insert Nut (inserted)		4
J	5/16" x 30mm Hex Bolt		16
L	Z Hex Wrench 5mm (included)		1
М	1/4" x 13.5mm Insert Nut (inserted)		1
N	#8 x 2" Black Screw (inserted)		8
0	5/16" x 10mm T-Nut (inserted)		16
Р	Straight Hex Wrench 5mm (included)		1
Q	Slotted Leveler (installed)		5
R	Leveler Adjustment Key (attached to Owners Ma	anual)	1

2420DUETb Addi Writing Desk


Assembly Instructions

Tools Provided: Z Hex Wrench 5mm, Straight Hex Wrench 5mm (use with drill/driver), Leveler Adjustment Key in the Zip bag taped to the Owner's Manual and Safety Guide.

1. Turn the Top Assembly (Aa) upside down on a clean, protected surface. Remove the Drawer (B) and place it off to the side. See Figure 1.




2. Attach four Legs (C) to the Top Assembly (Aa) with sixteen 5/16" x 30mm Hex Bolts (J). See Figure 2.



2420DUETb Addi Writing Desk

Assembly Instructions

3. Turn the desk upright and insert the Drawer (B). Place the desk at its final destination. Use the Leveler Adjustment Key (R), found in the Zip bag taped to the Owner's Manual and Safety Guide to rotate the Slotted Levelers (Q) on the bottoms of the legs until the unit is level. See Figures 3 and 3a.



4. This item includes an adjustable drawer stop to allow for adjusting the alignment of the profile of the drawer front to the profile of the Top Assembly. To adjust the alignment rotate the Slotted Levelers (Q) as needed. See Figures 4 and 4a.

